

User instruction

Lamp, Molecular Cb0811

Technical Data: -

Supply voltage: - 230 V AC, 50Hz

Rating: - E-27 lamp holder

Max 1x25 W 230V AC 50Hz IP-20 

Warning:

A: Always call a professional/qualified electrician for installation of the lamp.


B: Switch OFF the main electric supply before starting installation/wiring of the hanging lamp.

Maintain interior cleaning with a dry cloth duster. Do not use abrasive or solvent. Avoid the use of liquid on all electrical parts.

 This means that the product can be installed at a normal flammable material surface.



STEP
1



Ceiling plate attached with lamp shade.

STEP
2



Unscrew this plate from the screws shown with the help of a screwdriver.

STEP
3




Fix the upper part of the ceiling plate to the ceiling box with screws.

STEP
4



Lower part of the ceiling.

STEP
5



Fix the ceiling cover plate and secure it with the help of screws. Make sure the holes on the upper and lower part are aligned.

STEP
6



Do electrical connections as shown on the picture.
(a) Brown Wire-L
(b) Yellow/Green Wire-E
(c) Blue Wire-N

Now the pendant is ready for use.



house doctor